

DELTA Loop Status and Future Plans


AFC Semiannual Review
January 2003
Valentina Tcharnotskaia

DELTA Loop at LANL TA-53




Multipurpose Liquid Metal Testing Facility

- DELTA Loop offers tested robust and reliable operation.
- Sophisticated Data Acquisition and Control system provides management of necessary functions and collects variety of data.
- Design and procedures ensure safe operations.
- Design allows expansion to other working fluids and operating conditions.





DELTA Loop Upgrades Since January 2002

- Gas system was modified, new valves and additional pressure transducers were installed to improve control and gas flow stability.
- Lead-bismuth pressure transducers were replaced several times. New gas system was designed and connected to the pressure transducers to prevent their failure in the future.




DELTA Loop Upgrades Since January 2002

- Oxygen sensors were fitted with a protective sheath and replaced. Welded fittings were replaced. Cleaning gas injection inlet tube was replaced with better level sensors arrangement.





DELTA Loop Upgrades Since January 2002

- Magnetic flow meter was replaced with a venturi flow meter for more stable measurement.




DELTA Loop Upgrades Since January 2002

- Heating zones were rearranged for more uniform temperature control and better electrical balance. Heaters' breakers and relays were upgraded.
- Heat Exchanger water and gas leaks were eliminated.



DELTA Loop Upgrades Since January 2002

- Data Acquisition Hardware was upgraded. New hardware was installed to accommodate new instrumentation and controls.
- Additional program was written to allow access to main program via internet.
- DELTA Loop Hazard Control Plan and procedures were updated based on testing experience and new controls.




DELTA Loop Experiments and Tests Since January 2002

- DELTA loop has run 123 hours.
- Shakedown runs to test equipment and procedures.
- Continuous 48 hour run.
- Maximum Temperature: 425°C, Maximum flow speed: 7.6m³/hr.
- Magnetic Flow Meter Calibration.
- Venturi Flow Meter Calibration.
- Cleaning gas injection system tests.
- LBE pressure transducers gas line tests.
- Numerous shut down conditions tests.




Venturi Flow Meter Calibration Successful

Venturi flow meter calibration was performed successfully.
Resulting calibration curve is consistent with predicted values.




Example of DELTA data




Material Samples are Ready

- Material Samples of Stainless steels 316L, HT9, T91, EP823, 316L welded to T91 and Tantalum, Iron, Iron-Silicon alloys, Alumina are ready for testing.



Welded 316L /T91 corrosion samples




Alumina corrosion samples



HT9 tensile samples

Samples Holder is Ready

- Materials samples holder segments were machined.
- There are nine sections held together by a center rod in the holder.
- Holder hangs from the top of test section.



Objectives

- Oxygen sensor seal reinforcement.
- Material tests complete in April 2003:
 - 333 hour, 666 hour and 1000 hour durations.
 - Oxygen content controlled.
 - Temperature gradient 100°C.
 - Flow speed 2m/s at materials samples.
- Higher temperature test section design complete in April 2003.
Installation in May 2003.
- 2000-3000 hour test start June 2003.

High Temperature Testing

- Reasons:
 - Interest from Generation IV nuclear reactor designs.
 - Liquid lead testing.
 - Lack of data at higher temperatures.
- New requirements:
 - Temperature up to 650°C.
 - Material different from 316 stainless steel, such as HT9.
 - Special heat exchanger can be designed using existing designs.
 - Different working fluid may need a separate drain tank.
- Similarities:
 - Lead thermodynamic properties are similar to lead-bismuth. Stress due to fluid is similar.
 - Loop piping can be designed to connect higher temperature test section with minimal additional stresses.

Lead vs. Lead-bismuth

	<i>Lead</i>	<i>Lead-Bismuth</i>
<i>Density</i>	10500 kg/m ³	10300 kg/m ³
<i>Viscosity</i>	1.8×10 ⁻⁷ m ² /s	1.6×10 ⁻⁷ m ² /s
<i>Specific heat</i>	147.4 J/kg °C	146.5 J/kg °C
<i>T melt</i>	327.4°C	123.5°C
Thermal Expansion	0.00011 m ³ / m ³ °C	0.00011 m ³ / m ³ °C
Latent Heat	24.1 J/g	22.5 J/g
Expansion on Melting	3.4% volumetric	1.5% volumetric

DELTA Loop Available for Higher Temperature Testing

- Additional test section and auxiliary components can be designed within a year.
- DELTA loop can be utilized for lead and lead-bismuth testing.
- DELTA loop is already equipped for complete and extensive tests:
 - Sophisticated instrumentation already exists.
 - High fluid flow capacity.
 - Variable flow paths.
 - Operating experience.

