Advanced Accelerator Applications Technical Quarterly Review

(Covering January-June 2002)


LBE-Related Technology
WBS 1.25.04

Ning Li July 10, 2002

Milestone Performance in 2nd-3rd Quarters, Jan.-June, FY02

Milestones	M/S Level	Baseline	Status
Receive oxygen sensors for unattended operations	3	4/11/02	Ahead of schedule
Issue oxygen control and calibration strategy report	3	5/31/02	On time
Complete operational tests including sensor calibrations	3	4/29/02	Delayed: various small defects, delays and improvements; will be ready for corrosion test before August
Approval of unattended operations	2	4/29/02	Ahead of schedule


Highlights for DELTA Loop Operations Jan.-June, FY02




- Operated for over 70 hours at temperatures up to 400°C
- Stable output from the oxygen sensors
- Variable flow speeds up to 35GPM (8m³/hr)
- Natural convection flow at 1m³/hr
- Operated in isothermal regime and and with temperature gradient
- Unattended operations approved and under testing
- Upgraded and tested cleaning gas injection system including forming and melting the freeze plug and maintaining constant cleaning gas pressure
- Data acquisition and control system including shut down controls proved reliable

Magnetic Flow Meter Calibration

MFM Calibration 3-12-02



Stable Oxygen Sensor Output at Expected Values in DELTA Loop



Unattended Operations of DELTA Approved and Under Testing

- DELTA loop design and operation underwent a readiness review and received authorization to run unattended on April 25th
- The following conditions are implemented as part of unattended operations
 - Interlock and other safety controls are tested periodically.
 - HCP and procedures ensure control of safety settings such as max/min temperatures.
 - Autodialer notifies system operators of shut down conditions.
 - Remote viewing of the operational data is available

FY02 Corrosion Test Plan Finalized

Objectives

- Operation performance test for extended unmanned test operations with oxygen control
- Short term test of MEGAPIE window candidate materials and several variations of alloys and surface treatment

Goals

- Achieve stable test operations with oxygen control over extended period
- Provide performance data for the MEGAPIE window candidate materials for one specific (slightly more stressed) condition
- Provide data to understand the protective oxide growth and repair mechanisms and kinetics

Materials Selection to Meet Programmatic and Scientific Objectives


- Programmatic (corrosion and tensile specimens)
 - T91 (MEGAPIE window candidate material), HT-9 (alternative)
 - EP823 (reference Russian alloy)
 - 316L (base material for LBE systems)
 - T91/316L weld (MEGAPIE design)
- Scientific (corrosion specimens)
 - Ta
 - Si-Fe alloys (role of Si for enhanced corrosion resistance)
 - CEA Al-316L, FZK GESA-treated 316L (surface treatment)


Temperature and Flow Conditions: Slightly More Stressed than MEGAPIE

- Temperature
 - 500°C max, 100°C gradient (MEGAPIE T_{in} ~240, T_{out}~340, T_{win.max}~380°C)
- Flow
 - 2 m/s max design limit before onset of erosion (MEGAPIE V_{max} < 1.5 m/s)
- Oxygen Control
 - 10⁻⁶ wt% mid-range of oxygen control regime
- Time Intervals
 - 333, 667, 1000 hours

Specimens and Holders in Fabrication

- Corrosion and Tensile Specimens
 - 8mm W x 35mm L x 1mm T
- Sample Holder Design and Specimen Arrangement Finalized
 - Each holder holds 32 specimens
 - 6 holders arranged in series in the test section
 - CFD-aided design to homogenize flow distribution
 - Entrance flow conditioning via extra 3 holders and specimens upstream





DELTA Plan for Rest of FY02 and FY03

- 333 hour, 667 hour and 1000 hour material tests will be conducted before the end of the fiscal year
- Corrosion probes will be designed for and tested (FY03) in the loop
- More long term materials tests will be planned for FY03 (with extension of test temperature)
- Extension of capability for erosion/corrosion tests will be planned FY03
- Thermohydraulic tests will be planned for FY03
- New flow measurement techniques will be investigated

Developing Integrated Test Plan for LBE Technology Development

Program Drivers

- ADS/Transmutation: US ATW/AAA, EU P&T(MEGAPIE, XADS, MYRRAH),
 Japan P&T, S. Korea HYPER
- Advanced Reactors: US NERI/NEER/Gen IV, GIF, Japan FR Commercialization, EU MICA/"Michelangelo"

R&D Facilities

- US: LANL DELTA Loop and LBE technology development experiments, UNLV TC-1 and lab, small loops/experiments at ANL, INEEL, MIT
- Germany: FZK KALLA and associated labs
- France: CEA CICLAD, CNRS small experiments
- Switzerland: PSI LiSoR
- Japan: JAERI, TIT loops and experiments
- Russia: Loops and labs
- Italy: ENEA/Ansaldo CIRCE
- Spain: CIEMAT small experiments
- Sweden: RIT loop

LBE R&D Facilities and Program Focus

Organization	Facility	Capability	R&D Focus	Status
LANL, US	DELTA Loop (LBE technology development experiments)	Oxygen control, T<550°C, v<5m/s, V~0.35m³, 100kW effective heating, natural convection, large and flexible test section	Materials and thermal hydraulic testing (Oxygen sensor, control, calibration, corrosion modeling, corrosion probes, UDV etc)	Operational
UNLV, US	TC-1	EMP, V~0.068m³, 600kW heat removal capacity	Benchmarking experiments for materials, heat transfer and thermal hydraulic studies	Delivered
FZK, Germany	THESYS(1) THEADS(2) CORRIDA(3) (supporting labs)	Oxygen control, T<550°C, (1) V~0.1m³, EMP, (2) V~4m³, 4MW heating, (3) V~0.03m³, sampling ports, in-situ mechanical tests	(1) Technology development, (2) thermal hydraulic testing, (3) corrosion testing	(1) Operational(2) Start '02(3) Start '03,extend toT<650°C
CEA, France	CICLAD (static test experiments)	Low oxygen, EMP, rotating cylinder, v _s <6m/s (v _t <0.1m/s), T<650°C	Corrosion testing (surrogate spallation products)	Operational
ENEA/Ansaldo, Italy	CIRCE	Pool test, T<550°C, 90 T LBE, natural and enhanced circulation, 1MW heating	Engineering testing	Operational
RIT, Sweden	Loop		Natural convection and heat removal from reactor core	Under construction
TITech, Japan	Loop	Oxygen control, T<550°C, v<2m/s, V~0.022m³, 22kW heating	Corrosion testing Operational	

Highlights for LBE Technology Development Jan.-June, FY02



Oxygen Sensors installed in DELTA

 Start of hydrogen/steam mixture system to calibrate oxygen sensors


 Oxygen control methodology and calibration strategy report issued


 Corrosion modeling improved the model prediction and mapped the average corrosion rate of DELTA Loop (2 papers under preparation)

 A TRAC model for DELTA established to benchmark the modification incorporating LBE features (validated TRAC will be used to support MEGAPIE safety studies)



Testing Oxygen Sensor Calibration System





Gas Phase Oxygen Control Methodology

Gas Phase Oxygen Control

- Direct injection of oxygen and hydrogen into either LBE or cover gas over flowing LBE surface (implemented in DELTA Loop)
- Injection of hydrogen/steam mixture that will produce the desired oxygen level at equilibrium (in testing for sensor calibration)

Advantages

- Simple design
- Gas in/gas out
- Hydrogen/steam mixture can be used for calibration
- Hydrogen at high throughput can be used for sparging and restoration of LBE systems

Disadvantages

- Gas line pressure regulation needs to be carefully design for and controlled
- Gas/liquid mass exchange is not efficient
- Prone to excess slag formation

Solid Phase Oxygen Control Methodology


- Solid Phase Oxygen Control
 - Solid lead/bismuth oxide spheres in a porous container in a bypass
 - Release controlled via temperature, flow and duration
 - Possible use of solid hydride for cleaning
- Advantages
 - Efficient mass exchange
 - Little slag formation, less coolant contamination
- Disadvantages
 - Oxide inventory limited
 - More R&D needed to prove performance

Oxygen Sensor Calibration Strategy

- Oxygen Sensor Calibration Strategy (Standard)
 - Using hydrogen/steam mixture to attain absolute partial pressure of oxygen in the desired range (also adopted by CEA, FZK and TECLA)
- Alternative Strategies
 - Using solubility limit of oxygen in LBE for one set of curves (relying on IPPE solubility data)
 - Using oxide dissociation limits (NiO, Fe₃O₄, Cr₂O₃, etc)
 - Cross-calibrate sensors with various reference electrodes (Bi/Bi₂O₃, In/InO₂, Pt/air)

Progress on Modeling System Corrosion

- Improvement of the mass transfer coefficient based prediction of corrosion rate in test loops (incorporate the effect of bulk concentration of corrosion product through system calculation)
- Mapping of the (average) corrosion rate as a function of the hot test section temperature and temperature difference in DELTA Loop




TRAC Modeling of DELTA Loop and Benchmarking with Test Data

Status as of June 30, 2002

- Developed A TRAC model of the DELTA Loop
- The model reflects correct pipe sizes, elevations, and calculated loss coefficients
- The model has been checked and calculated to steady state at several different assumed mass flows and power settings
- DELTA Loop test data is being obtained to benchmark the TRAC model
- The TRAC model will then be updated to include trace species tracking for corrosion modeling
- TRAC will be used to support MEGAPIE safety studies

DELTA Loop TRAC Model



International and University Collaborations for LBE Technology Development

International

- CEA (France): CICLAD/DELTA corrosion tests coordination, Al-316L corrosion test specimens for DELTA delivered
- MEGAPIE: recommendation of oxygen control strategy (to avoid liquid metal embrittlement) and LANL sensors; agreement to adapt TRAC to support safety studies
- TECLA (EU): exchange of reports with oxygen sensor working group
- FZK (Germany): oxygen control systems, GESA-treated 316L corrosion test specimens
- RIT (Sweden): request of LANL oxygen sensors for natural circulation experiment (experimental data in return)

University

- UNLV: test plan, delivery and inspection of LBE loop; project supports
- MIT: Si-Fe alloys for DELTA test
- Visits Received at DETLA Loop in FY02
 - 13 (7 international; 6 universities; total 31 persons)

FY03 R&D High Priority Tasks

- Corrosion analysis of test specimens
- Improvement of oxygen sensors for lower operating temperature
- Test and improvement calibration and control systems
- Corrosion modeling (including TRAC) and comparison with data
- Effects of (surrogate) spallation products on coolant chemistry and corrosion
- Thermal hydraulic testing
- Development of plans to measure thermodynamic and transport properties relevant to LBE technology
- International (FZK, CEA/CNRS, MEGAPIE, TECLA, JNC, RIT etc) and university (UNLV, MIT) collaborations